HOME ACCENTS Holiday

Christmas Tree
Model:MEAT66151200SEC
Sku # 1000 048 832

Safety Information

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed, including the following:

a. **READ AND FOLLOW ALL SAFETY INSTRUCTIONS.**

b. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.

c. This seasonal product is not intended for permanent installation or use.

d. Do not mount or place the product near gas or electric heaters, fireplaces, candles, or other similar sources of heat.

e. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.

f. Do not let lamps rest on the supply cord or on any wire.

g. Unplug the product when leaving the house, when retiring for the night, or if left unattended.

h. This is an electric product and not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.

i. Do not use this product for other than its intended use.

j. Do not hang ornaments or other objects from cord, wire, or light string.

k. Do not close doors or windows on the product or extensions cords as this may damage the wire insulation.

l. Do not cover the product with cloth, paper, or any material that is not a part of the product when in use.

m. This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless plug can be fully inserted. Do not alter or replace the plug.

n. This product is equipped with push-in type lamps. Do not twist lamps.

o. This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product.

p .Read and follow all instructions that are on the product or provide with the product.

q. **SAVE THESE INSTRUC TIONS**

Pre-Assembly

Package Contents

Part	Description	Quantity
A	Tree top, tag 4	1
B	Tree center 1, tag 3	1
C	Tree center 2, tag 2	1
D	Tree bottom, tag 1	1
E	Tree stand	1

Assembly

Assembling the tree stand

Step 1. Pull apart the legs of the stand so that they are snapped into an x-shape, place the tree stand on a level surface.

Step 2. When inserting the bottom section of the tree into the assembled stand, insert and turn the eyebolts into the stand and tighten until the tree pole is firmly secured.



To close the stand, remove the eyebolts, press the metal button and fold the legs together.



Assembling the tree

This tree assmebles with Quick Set® technology ---Set up and light up your tree in less than 10 minutes!

Step 1. Remove the protective caps from the tree bottom (D) and insert the pole into the tree stand (E).

Step 2. Remove the protective caps from the tree center 2 (C) and insert the pole into the tree bottom (D).